

CoolBot[®]


Sensor Calibration Check

Applicable to all Models


1. Gently slip the Fins Sensor out of the fins of the A/C unit



2. Place your Fins Sensor next to your CoolBot's Room Sensor



3. Allow a minute or so to let the sensor settle to the room temperature
4. Toggle between Room and Fins with the right and left arrows to compare the values



5. With the aid of a **reliable calibrated digital thermometer** (positioned next to the 2 sensors) compare the readings of the sensors and the thermometer
6. They should be within 2F degrees of each other and from the external thermometer.
7. If all sensors check OK, place your Fins Sensor back into the fins of the A/C.
8. If one of the sensors is out of calibration discard and replace. Put your Coolbot in the **Workaround Mode**.

Watch our [Sensor Calibration Test video](#)

Watch our [Workaround Mode video](#) or our Workaround Guide

To get a replacement sensor under warranty (1 Year) please email support@storeitcold.com

To order new sensors please go to: <https://www.storeitcold.com/coolbot-accessories/>