





EF Message on Display

Not Applicable to 2G Model (CoolBot with cables on top and side)

1. A blinking **EF (or Er)** on the CoolBot display means there is a problem with the Fins Sensor.



2. Unplug the Fins Sensor, clean the connector jack (tip) and replug your Fins Sensor 2 times.



3. If the error clears we are good! Perform a **Calibration Test**
4. If the error persists discard the sensor and replace. Put your Coolbot in the **Workaround Mode**.

Watch our [Sensor Calibration Test video](#)

Watch our [Workaround Mode video](#) or our Workaround Mode Guide

To get a replacement sensor under warranty (1 Year) please email support@storeitcold.com

To order new sensors please go to: <https://www.storeitcold.com/coolbot-accessories/>