


CoolBot[®]

Workaround Mode


Not Applicable to 2G Model (CoolBot with cables on top and side)

If you have a bad sensor (Room or Fins) discard it. The CoolBot can work in a Safety Mode with one good sensor. The good sensor **MUST** be plugged into the Fins port.


- If your Room Sensor is bad, unplug it and discard it. **Leave the Room port empty.** Your CoolBot will read **Er** on the display. This is OK! Your CoolBot is now on the workaround Mode




- If your Fins Sensor is bad:
 - a. Unplug your Fins Sensor and discard it. **DO NOT** use it!



b. Unplug your Room Sensor and Plug it into the Fins port



c. Leave the Room port empty. Your CoolBot will read Er on the display. This is OK! Your CoolBot is now on the workaround Mode



To get a replacement sensor under warranty (1 Year) please email support@storeitcold.com

To order new sensors please go to: <https://www.storeitcold.com/coolbot-accessories/>